

Fork Slot Truss Jibs

Fork Slot Truss Jib - Jib accessories are made so as to be used on industrial forklifts, extendable-reach forklifts, and on rough terrain straight-mast forklifts. Forklift jib cranes install onto the forklift through inserting two forks into the fork pockets. The back of the jib crane then seats towards the back of the fork and a safety chain wraps the forklift carriage to hold it into position.

Load Capacity for the Jib Boom Forklift Attachment

The most load capacity for forklift jibs in both the extended or retracted positions range from 1935 pounds to as much as 6000 lbs. It's a good suggestion to ask a material handling specialist concerning the limits for your particular use. The load capacity rankings are for the jib itself and not the lift truck or the maximum load that could be carried securely with a particular lift truck. It is very important remember that at any time when whichever attachments such as a forklift jib are added to the forklift, the new center of gravity made by the attachment will reduce the general lift capacity of the forklift. There are directions accessible that offer details on how to correctly gauge these load limits.

Prior to utilizing whichever forklift jib, be sure that the shackles and hooks are correctly secured to the forklift. Be sure and also double check that the pins are tight. It is very important that the weight calculations are properly made and double checked. Remember to take into account the fact that rated capacities sometimes lessen when the boom is in an elevated position, every time the boom is extended with telehandlers or even every time the mast is tilted forward.